






1.



2.



BATTERIES
NOT INCLUDED!

3.

∞ PAIRING:


Lamp OFF and charging, press on top of the lamp > 4 s

1. > 4 s




BLUE FLASH
READY TO PAIR

2.



GREEN FLASH AND BLUE FLASH TOGETHER
PAIRING OK

4.





5.

*** DIMMER/

COLOUR TEMPERATURES:


Lamp ON, press wanted features



6.

🔒 LAMP SWITCH LOCK:

Lamp ON, press




BLUE FLASH ONCE
LAMP SWITCH LOCKED

7.

🔒 LAMP SWITCH UNLOCK:

Lamp ON, press




BLUE FLASH TWICE
LAMP SWITCH UNLOCKED

8.

∞ UNPAIRING:


Lamp charging, press on top of the lamp > 4 s

ALT. 1



BLUE FLASHES TWICE TOGETHER
UNPAIRING DONE

ALT. 2.



REMOTE ON LAMP TOP
PAIRING LOST